

Motorradzubehör Hornig GmbH

Install instruction handlebar risers
Article-No.: LA048-0150

F800GT



Handlebar dismantling:

Remove the four screws from the terminal block and take the handlebar off.
Then also unscrew the terminal block from the triple clamp.

Mounting of the handlebar with article no. LA048-0150:

Apply the risers (20mm) so that the side which is convexed outward is overhead.
Lay the included washers on the triple clamp (in rare cases this can be omitted), position the original washers in the terminal blocks and pre-mount the included screws M10x90.

Now put the handlebar risers between the triple clamp and the terminal blocks and align roughly. Subsequently tighten them with the original nuts and the washers.
Please absolutely use medium strength screw lock!
Then re-mount the handlebar, the clamping pieces and all fairing parts.

Tightening torque of the screws max. 25 Nm

Turn the handlebar in both directions after the completed mounting.
Thereby take care that all cables and wirings will have enough space even with full steering angle. After you have driven 50km check and tighten the screws again.

General hint:

We are not liable for any improper and unprofessional installation and for the use of other parts or screws than described.

With street homologation (European homologation, EG ABE) type LA